


Victorian Lidded Box

#P12-13



#P12-13 Victorian Lidded Box			
Description	Item	Qty	Size
Lid	A	2	1/8" T x 4 1/2" W x 5 1/2" L
Side	B	2	1/8" T x 3 3/4" W x 9" L
End	C	2	1/8" T x 3 1/2" W x 4 3/4" L
Bottom	D	1	1/4" T x 4 3/4" W x 9 3/4" L

- #P12-13 Assembly Instructions
1.

Select your material from a variety of hardwoods or solid core plywood.
2.

Measure each pattern piece and cut the work pieces to size accordingly. Sand as necessary.
3.

Make all pattern pieces by adhering the paper patterns to the work pieces with a repositionable spray adhesive. Cut the outer shapes and any interior designs. And drill where indicated.
4.

Remove all paper patterns. Sand where needed. The edges can be rounded by sanding or using a small roundover router bit if desired.
5.

Assemble by first attaching the Sides to the Bottom, securing with glue. Next, attach the Ends. Slide the Lids through the slots in the Ends. Finish as desired.

